

HerbsNOW Storage Container

Instructions for Use

To Remove Vacuum Seal and Open Lid

1. Check Vacuum Seal Indicator. Do not open lid when indicator shows a seal is in place.
2. Pull up on the Vacuum Release Valve. You will hear air release from the container.
3. The lid can now be removed from the container. Grasp the edge of the lid and pull up to release it from the container.

To Vacuum Seal Container

1. Place lid on container.
2. Rotate Vacuum Pump to "ON" position. Pump will be elevated from lid when in ON position.
3. Press down on the Vacuum Release Valve to close it.
4. Pump the Vacuum Pump a maximum of 30 times. The Vacuum Seal Indicator will depress into the lid.
5. Press down on the Vacuum Pump and rotate to the "OFF" position.

